



Minimum space between holes should be 4mm.

END BRACKET DIMENSIONS

unit: mm

Table 3

Chain No	I	J	K	L	M	N	O	Q	V	X	W
KC 38	B+4.0	14	B-24	50	10	30	25	6.4	4	2.0	B+23
KC 60	B+4.6	13.3	B-22	60	15	30	28	8.8	5	2.3	B+27
KC 60H	B+6.4	14.7	B-23	60	15	30	29.3	8.8	5	3.2	B+31
KC 75	B+6.4	24.2	B-42	80	15	50	40	8.8	10	3.2	B+39
KC 75W	B+6.4	24.2	B-42	80	15	50	40	8.8	10	3.2	B+39
KC 100	B+9.0	25	B-41	100	20	60	47	14	10	4.5	B+48
KC 100-2	B+39	35	B-31	100	20	60	65	14	10	6.0	B+71
KC 125-2	B+39	42	B-45	125	25	75	75	18	10	6.0	B+68

SUPPORTER DIMENSIONS

unit: mm

Table 4

Support No	X	A	Supporter dimensions B													Applicable Chain no		
			60	80	100	125	150	200	250	300	350	400	450	500	550		600	
SA 35	18	35																KC38KC60KC60H
SA 45	27	45																KC60 KC60H
SA 50	32	50																KC75 KC75W
SA 65	46	65																KC75KC75WKC100 KC100-2
SA 75	55	75																KC75W KC100
SA 90	60	90																KC100-2 KC125-2
SA 110	80	110																KC100KC100-2KC125-2

X is the maximum diameters of hose and cable to be carried.